

INSTALLATION INSTRUCTIONS FOR STA-RITE'S STEPS

1.
Before installing steps, paint the interior of each hole with a mixture of pure cement and water. Mix to the consistency of thick cream to make a waterproof seal.
2.
Fill the back of each step with grout for strong, solid installations.
3.
Fill hole with enough grout to prevent any voids behind step when it is pressed into place. Check steps for horizontal alignment and proper vertical spacing. Position the front face of steps approximately $\frac{3}{8}$ " out from pool wall in order to be flush with finished plaster surface.
4.
Work in grout around all sides as shown so that the locking flanges will permanently anchor step into the wall.

NOTE:

Do not install steps in freezing climate areas. Frozen pool water expands upward and will damage the projecting lip of step.

